

**SPECIFICATION SHEET**

**JFW MODEL 50PA-1174-XX**

**PROGRAMMABLE ATTENUATOR ASSEMBLY**

JFW Industries, Inc.  
Phone: 317-887-1340  
sales@jfwindustries.com  
www.jfwindustries.com

Frequency Range	200-8000 MHz
Attenuation Range	0-63 dB in 0.5 dB steps
Configuration	Individually controlled solid-state programmable attenuators. Number of attenuators can be selected from 1 to 8 attenuators.
Enclosure Type	19 inch rack mount 2RU high (for 1-8 attenuators)
Impedance	50 Ohms nominal
Startup/Default States (configurable)	Maximum attenuation (see ATTEN command) DHCP enabled (see NET command) 4 Ethernet users (see NET command) Prompts off (see PROMPT command)  All of these default settings can be changed by user. Unit can be configured for up to 12 Ethernet users.
VSWR	1.8:1 maximum < 1.6:1 typical
Attenuation Accuracy	± 0.25 dB            0.5-6.5 dB ± 0.50 dB            7-14.5 dB ± 1.00 dB or 3%    15-63 dB (whichever is greater)
Insertion Loss	5.3 dB maximum 2.3 dB typical @ 200 MHz 2.9 dB typical @ 2000 MHz 4.6 dB typical @ 8000 MHz
RF Input Power	+24 dBm (operating - Input Side) +15 dBm (operating - Output Side)  +25 dBm (no damage - Input Side) +16 dBm (no damage - Output Side)
Switching Speed	1 microsecond typical (after command is received and processed) (3 milliseconds typical processing time)
Manual Control	20-Button Keypad and LCD display (IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

**--CONTINUED--**

**SPECIFICATION SHEET**

**JFW MODEL 50PA-1174-XX**

**PROGRAMMABLE ATTENUATOR ASSEMBLY**

JFW Industries, Inc.  
Phone: 317-887-1340  
sales@jfwindustries.com  
www.jfwindustries.com

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)  
RS-232 (up to 115200 Baud)

Remote Commands Attenuator Control Commands:  
Atten, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover

System Commands:  
Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime, Prompt

RF Connector N female or SMA female

Operating Temperature Range 0°C to +50°C

AC Supply 100-240 VAC @ 47-63 Hz

Outline Drawing Number 092-9418-01 (1-8 attenuators with SMA)  
092-9418-02 (1-8 attenuators with N)

Available Model Numbers  
50PA-1174-01 SMA (1 attenuator)  
50PA-1174-02 SMA (2 attenuators)  
50PA-1174-03 SMA (3 attenuators)  
50PA-1174-04 SMA (4 attenuators)  
50PA-1174-05 SMA (5 attenuators)  
50PA-1174-06 SMA (6 attenuators)  
50PA-1174-07 SMA (7 attenuators)  
50PA-1174-08 SMA (8 attenuators)  
50PA-1174-01 N (1 attenuator)  
50PA-1174-02 N (2 attenuators)  
50PA-1174-03 N (3 attenuators)  
50PA-1174-04 N (4 attenuators)  
50PA-1174-05 N (5 attenuators)  
50PA-1174-06 N (6 attenuators)  
50PA-1174-07 N (7 attenuators)  
50PA-1174-08 N (8 attenuators)

Future Expansion If your testing needs change, you can have your 50PA-1174-XX upgraded to have additional attenuators. This model is designed to control up to a maximum of 8 attenuators.

ECR/ECN #	DATE	REV	APPR / DATE	ECR/ECN #	DATE	REV	APPR / DATE
	05/06/2020		TRS 05/06/2020				
30401	05/29/2020	A	TRS 05/29/2020				